

Changing Eprom

Static electricity can destroy the Eprom. If you have to replace the Eprom yourself, make sure that you are earthgrounded. You can for instance stand barefooted on a stone floor while you handle the Eprom.

Make sure that you do not mount the new chip upside down. The indent shall be up!

