## **Duplimate questionnaire**

Please fill out this form if you for some reason cannot use the Report problem function that you find in the DupSoft program

## **KEY DATA**

#	Hardware/software	Remark/Requested info		
1.1	Machine no	1.1.1 Using USB-RS232 adapter		
1.2	Machine firmware	See the About dialog		
1.3	DupSoft version	See the About dialog		
NO CARD DEALT				
#	Problem	Requested info		
2.1	Bands do not move in 3 sec at	2.1.1 Nothing happens		
	power on	2.1.2 Other (specify)		
2.2	No green light on the machine panel	2.2.1 Green light on the inside of the machine		
	<52 CARD	S AT STOP		
#	Problem	Requested info		
3.1	Card jam	3.1.1 Cards have jammed 3.1.2 No card jam, all cards go to N 3.1.3 No cards distributed		
3.2	Read error	3.2.1 All cards go to N		
3.3	Invalid barcode	3.3.1 Always same card		
3.4	Card already dealt	3.4.1 Specify which card was misread as what card		
3.5	Counter out of range	3.5.1 Count in msg = cards in board 3.5.2 Count in msg < cards in board		
3.6	Board out of position	3.6.1 Only dark coloured boards 3.6.2 Does not help to hold board in its inner pos.		
52 CARDS AT STOP				
#	Problem	Requested info		
4.1	Counter out of range	3.5.1 Count in msg = cards in board 3.5.2 Count in msg < cards in board		
	>52 CARDS			
#	Problem	Requested info		
5.1	No message	5.1.1 Machine has to be powered off		
5.2	Card jam			
5.3	Counter out of range	5.3.1 Always stop after 53 cards		
5.4	Card already dealt	5.4.1 Always at the 53rd card		

## 3.3/3.4 READ-ERROR REPORT

Please fill in this form if you get invalid barcode and/or card already dealt messages on various cards and therefore cannot fill in 3.3.1 and 3.4.1 respectively. When you get a bar-code error, tick one box and report which card that was misread.

	Error message (on the screen)	The last card dealt to North was
1 🖺	Invalid bar-code Card already dealt. Card	
2 🗎	Invalid bar-code Card already dealt. Card	
3 🗌	Invalid bar-code Card already dealt. Card	
4 🗌	Invalid bar-code Card already dealt. Card	
5 🗌	Invalid bar-code Card already dealt. Card	
6	Invalid bar-code Card already dealt. Card	
7	Invalid bar-code Card already dealt. Card	
8 🗌	Invalid bar-code Card already dealt. Card	
9 🗎	Invalid bar-code Card already dealt. Card	
10	Invalid bar-code Card already dealt. Card	

#	Remark/Remedy/Reference	
2.1	See no_power.pdf	
2.2	No remedy if no other problem (lamp is broken); Otherwise see no_power.pdf	
3.1.1	Mechanical problem; card_jam.pdf	
3.1.2	Reader disconnected or dead; reader_problems.pdf	
3.1.3	ULN/watchdog probably faulty; nothing_happens.pdf	
3.2.1	Reader faulty or covered with dirt; reader_problems.pdf	
3.3	Replace card if 3.3.1 ticked; reader_problems.pdf	
3.4	Check the deck; reader_problems.pdf	
3.5.1	Probably mechanical problem; counters.pdf	
3.5.2	A card has passed the reader undetected; reader_problems.pdf	
3.6.1	The board switch is damaged or missing; board_switch.pdf	
3.6.2	Probably dirt covering the sensors; board_switch.pdf	
4.1.1	Probably mechanical problem; counters.pdf	
4.1.2	A card has passed the reader undetected; reader_problems.pdf	
5.1.1	Try to replace eprom, then contact support	
5.2	See card_jam.pdf	
5.3	Try to shade the machine, then contact support	
5.3.1	A card has passed the reader undetected; reader_problems.pdf	
5.4.1	Either put a joker between decks, or deselect "stop card" in hardware settings (html)	